



IMPACT625M

PART NUMBER	DESCRIPTION
IMP6SUJ	3/8" DRIVE IMPACT SPRING LOADED U-JOINT ADAPTER
IMPM608	8MM X 3/8" DR CR-MO IMPACT SOCKET - SHALLOW
IMPM608D	8MM X 3/8" DR CR-MO IMPACT SOCKET - DEEP
IMPM609	9MM X 3/8" DR CR-MO IMPACT SOCKET - SHALLOW
IMPM609D	9MM X 3/8" DR CR-MO IMPACT SOCKET - DEEP
IMPM610	10MM X 3/8" DR CR-MO IMPACT SOCKET - SHALLOW
IMPM610D	10MM X 3/8" DR CR-MO IMPACT SOCKET - DEEP
IMPM611	11MM X 3/8" DR CR-MO IMPACT SOCKET - SHALLOW
IMPM611D	11MM X 3/8" DR CR-MO IMPACT SOCKET - DEEP
IMPM612	12MM X 3/8" DR CR-MO IMPACT SOCKET - SHALLOW
IMPM612D	12MM X 3/8" DR CR-MO IMPACT SOCKET - DEEP
IMPM613	13MM X 3/8" DR CR-MO IMPACT SOCKET - SHALLOW
IMPM613D	13MM X 3/8" DR CR-MO IMPACT SOCKET - DEEP
IMPM614	14MM X 3/8" DR CR-MO IMPACT SOCKET - SHALLOW
IMPM614D	14MM X 3/8" DR CR-MO IMPACT SOCKET - DEEP
IMPM615	15MM X 3/8" DR CR-MO IMPACT SOCKET - SHALLOW
IMPM615D	15MM X 3/8" DR CR-MO IMPACT SOCKET - DEEP
IMPM616	16MM X 3/8" DR CR-MO IMPACT SOCKET - SHALLOW
IMPM616D	16MM X 3/8" DR CR-MO IMPACT SOCKET - DEEP
IMPM617	17MM X 3/8" DR CR-MO IMPACT SOCKET - SHALLOW
IMPM617D	17MM X 3/8" DR CR-MO IMPACT SOCKET - DEEP
IMPM618	18MM X 3/8" DR CR-MO IMPACT SOCKET - SHALLOW
IMPM618D	18MM X 3/8" DR CR-MO IMPACT SOCKET - DEEP
IMPM619	19MM X 3/8" DR CR-MO IMPACT SOCKET - SHALLOW
IMPM619D	19MM X 3/8" DR CR-MO IMPACT SOCKET - DEEP

VIM Tools

Tampa, FL 33610 USA

1(800) 249-9444 Fax 813-231-6305

www.VIMTools.com Email Sales@vimtools.com



@VIMTools