



TMS40

40 Piece Elite TORX® Master Set

PFS4T8	T8 TORX® DRIVER - 1/4" SQ. DR.	BTXLT25	T25 BALL TORX® DRIVER - 6" OAL - 1/4" SQ. DR.
PFS4T10	T10 TORX® DRIVER - 1/4" SQ. DR.	BTXLT30	T30 BALL TORX® DRIVER - 6" OAL - 1/4" SQ. DR.
PFS4T15	T15 TORX® DRIVER - 1/4" SQ. DR.	V45L-T30	T30 TORX® DRIVER - 4.5" OAL - 3/8" SQ. DR.
PFS4T20	T20 TORX® DRIVER - 1/4" SQ. DR.	V45L-T40	T40 TORX® DRIVER - 4.5" OAL - 3/8" SQ. DR.
PFS4T25	T25 TORX® DRIVER - 1/4" SQ. DR.	V45L-T45	T45 TORX® DRIVER - 4.5" OAL - 3/8" SQ. DR.
PFS4T27	T27 TORX® DRIVER - 1/4" SQ. DR.	V45L-T47	T47 TORX® DRIVER - 4.5" OAL - 3/8" SQ. DR.
PFS4T30	T30 TORX® DRIVER - 1/4" SQ. DR.	V45L-T50	T50 TORX® DRIVER - 4.5" OAL - 3/8" SQ. DR.
PFS6T40	T40 TORX® DRIVER - 3/8" SQ. DR.		
PFS6T45	T45 TORX® DRIVER - 3/8" SQ. DR.		
PFS6T47	T47 TORX® DRIVER - 3/8" SQ. DR.		
PFS6T50	T50 TORX® DRIVER - 3/8" SQ. DR.		
PFS8T55	T55 TORX® DRIVER - 1/2" SQ. DR.		
PFS8T60	T60 TORX® DRIVER - 1/2" SQ. DR.		
PFS8T70	T70 TORX® DRIVER - 1/2" SQ. DR.		
VS404S	E4 TORX® SOCKET - 1/4" SQ. DR.		
VS405S	E5 TORX® SOCKET - 1/4" SQ. DR.		
VS406S	E6 TORX® SOCKET - 1/4" SQ. DR.		
VS407S	E7 TORX® SOCKET - 1/4" SQ. DR.		
VS408S	E8 TORX® SOCKET - 1/4" SQ. DR.		
VS610S	E10 TORX® SOCKET - 3/8" SQ. DR.		
VS612S	E12 TORX® SOCKET - 3/8" SQ. DR.		
VS614S	E14 TORX® SOCKET - 3/8" SQ. DR.		
VS616S	E16 TORX® SOCKET - 3/8" SQ. DR.		
VS818S	E18 TORX® SOCKET - 1/2" SQ. DR.		
VS820S	E20 TORX® SOCKET - 1/2" SQ. DR.		
VS822S	E22 TORX® SOCKET - 1/2" SQ. DR.		
VS824S	E24 TORX® SOCKET - 1/2" SQ. DR.		
V45L-T10	T10 TORX® DRIVER - 4.5" OAL - 1/4" SQ. DR.		
V45L-T15	T15 TORX® DRIVER - 4.5" OAL - 1/4" SQ. DR.		
V45L-T20	T20 TORX® DRIVER - 4.5" OAL - 1/4" SQ. DR.		
V45L-T25	T25 TORX® DRIVER - 4.5" OAL - 1/4" SQ. DR.		
V45L-T27	T27 TORX® DRIVER - 4.5" OAL - 3/8" SQ. DR.		
BTXLT20	T20 BALL TORX® DRIVER - 6" OAL - 1/4" SQ. DR.		

VIM Tools

Tampa, FL 33610 USA

1(800) 249-9444 Fax 813-231-6305

www.VIMTools.com Email Sales@vimtools.com

